



WF-046

Wall Feed Thru for FLEXWELL® Elliptical Waveguide E46 and ES46



The kit consists of wall gland, a single rubber boot and tension clamp with two bolts.

Feature / Benefits

Elliptical Waveguide installation

- The wall gland provides a single entry in conjunction with a feed through plate
- It consists of a single rubber boot, wall gland and stainless steel clamp

Technical features

STRUCTURE

Product Type	Wall/Roof Feed-Through System
--------------	-------------------------------

MECHANICAL SPECIFICATIONS

Feed-Through Holes	1
--------------------	---

PACKAGING INFORMATION

Package Quantity	1
------------------	---

External Document Links

Notes